



PREPARING THE SURFACE

All Glamora wallcoverings must only be hung on smooth, even, perfectly primed, homogeneous, white substrates according to the instructions below.




NEWLY-APPLIED TOP LAYER OF PLASTER

Make sure that the surface is solid and dry and that there is no mould or rising damp. Apply an extra-fine, white-coloured, smooth skim finish to the entire surface using a suitable cement-based skim coat. To even out absorption and improve adhesion, apply one or two coats of acrylic primer in an aqueous dispersion suitably diluted as recommended by the manufacturer. Wait for the time required for drying before proceeding to the next step.



EXISTING PLASTERWORK OR SLIGHTLY UNEVEN SURFACE

Sand and remove any material that is coming off as well as any salty deposits and old peeling paint. Carefully clean the surface using suitable equipment and make sure it is completely dry, even and flat. Apply an extra-fine, white-coloured, smooth skim finish to the entire surface using a suitable cement-based skim coat. To even out absorption and improve adhesion, apply one or two coats of acrylic primer in an aqueous dispersion suitably diluted as recommended by the manufacturer. Wait for the time required for drying before proceeding to the next step.



CERAMIC COVERING

Carefully clean the surface using suitable equipment for ceramic or tiles and remove any traces of limescale. Make sure that the wall is completely dry. Apply a thin, light-coloured, smooth skim finish using a suitable (preferably cement-based) skim coat. Once this is dry, apply a second extra-fine, white-coloured, smooth skim finish using a suitable cement-based skim coat. To even out absorption and improve adhesion, apply one or two coats of acrylic primer in an aqueous dispersion suitably diluted as recommended by the manufacturer. Wait for the time required for drying before proceeding to the next step.

VIDEO TUTORIAL



INSTALLATION

Before starting to hang any Glamora wallcovering, make sure that the surface in question is completely dry, has a residual moisture content RH of < 2.0%, is free from dirt, pencil marks, dust, granules and damp stains. Any corners or edges to be covered must be plumb and perfectly level. Make sure that there are no drafts in the space where the wallcovering will be applied and that the temperature remains between 15 °C and 35 °C with no fluctuations.

1. Take everything out of the box, checking that you have received all the material necessary for the GlamDecor installation; specific Adhesive; installation manual; positioning diagram.
2. Remove the packaging, taking care not to damage the wallcovering. Read the provided installation manual and make sure the sheets correspond to the positioning diagram.
3. Dilute Adhesive in clean water according to the instructions on the pack. Shake the water vigorously. Pour all the powder contained in the bag into the water, continuing to stir. Wait 3 minutes. Stir again. The product is ready to use after 5 minutes.
4. Measure the width of the first sheet on the wall. Lightly mark this measurement on the wall in pencil, leaving a 2 cm margin on the left. All the sheets are numbered consecutively. Before positioning the first sheet, use a laser level or a plumb line to make sure that it is perfectly perpendicular to the floor.
5. Apply the adhesive to the wall, level with the first sheet to be applied (sheet no. 1), using a short-haired roller and a brush for the corners.
6. Start positioning the first sheet (sheet no. 1), making sure there is a little spare material at the top in order to compensate in the event that the wall is not completely plumb. Smooth the newly covered surface with a clean plastic trowel, from the centre to the edges, to eliminate any air bubbles and excess adhesive.
7. Lay the next sheet (sheet no. 2) and match it perfectly to the adjacent sheet, without overlapping them. Smooth the newly covered surface with a clean plastic trowel, from the centre to the edges, to eliminate any air bubbles and excess adhesive.
8. Immediately remove any excess adhesive from the wallpaper, the joins and the surrounding surface using the non-abrasive side of a damp sponge or a damp microfibre cloth (rinse often in warm, clean water). Gently press near the joins with the help of a silicone roller.
9. Continue hanging the subsequent sheets (sheet no. 3, no. 4, no. 5 and so on, until the last one) making sure that they adhere to the wall and that they are perfectly matched up.
10. Trim the edges at the top and bottom with a professional cutter, making a precise, clean cut.

WARNINGS:

- Before beginning installation, we recommend watching the dedicated video tutorial on the Materials page on www.glamora.it
- To ensure proper drying of the covered walls, a constant temperature of between 15 °C and 35 °C must be maintained and draughts avoided for 24/36 hours after installation.
- If a wallcovering is being installed, the contents of this Manual are understood to be known to the parties and acknowledged and accepted by you. For more information about our Conditions of Sale, please visit www.glamora.it

GLAMORA

WARNINGS

Any discrepancies and/or defects in the purchased product must be reported to Glamora in writing within eight days of receipt of the order. In any case, it is the Customer's duty to check and report any discrepancies/defects in the goods before installing the material itself. Failure to comply with the aforementioned terms shall result in the forfeiture of the warranty against defects of the goods sold in accordance with Articles 1490 and 1495 of the Italian Civil Code.

Glamora Srl
Via Berna, 12/14
41049 Sassuolo (MO) – Italy
T. +39 0536 076403
contact@glamora.it
glamora.it