

MAINTENANCE



Our accessories

We recommend to use WriteWallPaint whiteboard markers and other accessories.



Miracle cloth

For wiping, erasing and cleaning, WriteWallPaint surfaces always use the WriteWallPaint Miracle cloth, or a Microfiber cloth.



Miracle water for daily use

If it's time for a little extra cleaning, then use a clean Microfiber cloth, moistened with WriteWallPaint "MiracleWater". Dry with a dry and clean Microfiber cloth afterwards.



Miracle cleaner for extra dirt

For extra dirty surfaces apply WriteWallPaint "MiracleCleaner" or in bad cases use household alcohol; subsequently use a clean cloth, moistened in WriteWallPaint "MiracleWater" afterwards. – If needed then repeat.



Use only whiteboard materials

Never use: Abrasive materials such as scouring sponges, sharp objects and similar tools that could damage the surfaces. Never use ordinary pens, ball point pens, permanent markers, cleaning materials and objects that give off fat membrane or leave a chemical "film", products with acid or similar.